

Emergency Response Service Included on Iridium Extreme Satellite Phones



Programming and Testing Instructions

Programming Emergency Call and Message Recipients During Power-Up

- 1) Attach the standard battery to the Iridium Extreme and follow instructions provided for completing the installation.
- 2) Power on the Iridium Extreme phone by pressing the top power button located next to the SOS button.
- 3) The following message will appear if the emergency recipient has not been configured:

CAUTION! Emergency call recipient has not been configured.
Refer to user guide and edit.

- 4) If this message appears, press the left option key for "Edit" to program the call recipient.
- 5) Next, press the right option key for "Clear" to delete the "+" sign
- 6) Next, enter 3722 and then press the left option key to "Save"
- 7) Next, the following message will appear if the emergency message recipient has not been configured:

CAUTION! Emergency message recipient has not been configured.
Refer to user guide and edit.

- 8) If this message appears, press the left option key for "Edit" to program the call recipient.
- 9) Next, press the left option key for "Options"
- 10) Next, press the left option key for "Select" to "Edit" the message recipient
- 11) Next, press the left option key for "Select" to "Edit Number..."
- 12) Next, press the right option key for "Clear" to delete the "+" sign
- 13) Next, enter *3 and then press the left option key for "OK"
- 14) Next, press the right option key for "Back"
- 15) Programming is complete

In the event that the emergency call and message recipients have already been programmed or need to be edited in the future, follow these instructions:

Programming Emergency Call and Message Recipients from the Main Menu

Step 1: Access Emergency Options:

- 1) Press the left option key for "Menu"
- 2) Press the down arrow on the 2-way Navi Key until "Setup" is highlighted
- 3) Press the left option key for "Select" for "Setup"
- 4) Press the left option key for "Select" for "Location Options"
- 5) Press the down arrow on the 2-way Navi Key until "Emergency Options" is highlighted
- 6) Press the left option key for "Select" for "Emergency Options"

Step 2: Ensure "Message and Call" option is selected

- 1) Press the down arrow on the 2-way Navi Key until "Emergency Actions" option is highlighted
- 2) Press the left option key for "Select" for "Emergency Actions"
- 3) Make sure the "Message and Call" action is highlighted. If necessary use the 2-way Navi Key.
- 4) Once the "Message and Call" action is highlighted, press the left option key for "Select"

Step 3: Edit the Message Recipient:

- 1) Press the down arrow on the 2-way Navi Key until "Message Recipient" option is highlighted
- 2) Press the left option key for "Select" for "Message Recipient"
- 3) Press the left option key for "Edit" to program the call recipient.
- 4) Next, press the left option key for "Options"
- 5) Next, press the left option key for "Select" to "Edit" the message recipient
- 6) Next, press the left option key for "Select" to "Edit Number..."
- 7) Next, press the right option key for "Clear" to delete the "+" sign
- 8) Next, enter *3 and then press the left option key for "OK"
- 9) Next, press the right option key for "Back"

Step 4: Edit the Call Recipient:

- 1) Press the down arrow on the 2-way Navi Key until "Call Recipient" option is highlighted
- 2) Next, press the left option key for "Select"
- 3) Next, press the right option key for "Clear" to delete any numbers and the "+" sign
- 4) Next, enter 3722 and then press the left option key to "Save"

Step 5: Return to Main Menu and Completion of Programming

- 1) After completing steps 1, 2, 3, and 4, press the right red key to return to the Main Menu
- 2) Programming of emergency call and message recipients is complete.